

Base Stations

# WIRELESS WARNING MODULE

## BW-WM1

A visual and audible warning module to alert users of pre-defined status level set within the Broadweigh system



## Features

- 3 'traffic light' visual indicators
- Audible alarm
- Full user control and configuration
- Assignment of individual or group sensors
- Can be set to compare groups of weights to a set point; for example when hanging truss
- Can be latched / digital input for external reset
- Communication lost / error signal
- Up to 800 m range
- IP67 rated enclosure
- Optional mounting kit

## About

The BW-WM1 is a fully configurable three light warning indicator that can be used in a simple LOG100 mode. The green light extinguishes if there is a loss of signal from any transmitters. The amber light illuminates if any LOG100 display channel passes the warning level. The red light illuminates if any LOG100 display channel passes the over / underload level.

The module is fully user set for maximum control and configuration and can be configured on the sum of assigned shackles.

## Specifications

### Power Supply

External supply voltage	9 to 32 Vdc
-------------------------	-------------

### Environmental

Operating temperature range	-10 to 60 °C
-----------------------------	--------------

Storage temperature range (no batteries)	-40 to 70 °C
--	--------------

IP rating	IP67
-----------	------

Find out more

[broadweigh.com](http://broadweigh.com)

